

# Service Manual

Section 3

## Trucks

Electrical System

C303

CIVIL



# VOLVO





## Contents

### Group 30 General

Specifications .....	1
General Service Procedures .....	4
Terminal designations on different components .....	4

### Group 31 Batteries

Construction and Function .....	6
Capacity .....	6
Service Procedures .....	7
Changing the batteries .....	7

### Group 32 Alternator

Construction and Function .....	8
Alternator .....	8
Charging regulator .....	10
Service Procedures .....	10
General .....	10
Removing the alternator .....	10
Overhauling the alternator .....	11
Installing the alternator .....	14
Replacing the charging regulator .....	14
Charging test on test bench or in vehicle .....	14
Functional disturbances .....	16

### Group 33 Starter Motor

Construction and Function .....	17
Service Procedures .....	18
Testing the starter motor in vehicle .....	18
Removing the starter motor .....	18
Testing the starter motor in test bench .....	19
Functional disturbances .....	20
Overhauling the starter motor .....	20
Installing the starter motor .....	25

### Group 34 Ignition System

Construction and Function .....	26
Service Procedures .....	28
Ignition coil .....	28
Interference suppressors .....	28
Distributor .....	28
Ignition setting .....	31
Changing the breaker contacts .....	32

### Group 35 Lighting

Construction and Function .....	33
Service Procedures .....	34
Headlamps .....	34
Parking and direction indicator lights .....	35

Tail lights and reversing lights .....	35
Interior lighting .....	35
Instrument panel and switch lighting .....	36
Trailer contact socket .....	36

### Group 36 Direction Indicators and Hazard Warning Flashers, Horn, Windscreen Wipers and Washers, Switches and Relays

Construction and Function .....	38
Service Procedures .....	41
Direction indicators and hazard warning flashers ..	41
Horn .....	42
Windscreen wipers and washers .....	42
Switches .....	47
Relays .....	48

### Group 37 Electric Cables and Fuses

Construction and Function .....	50
Service Procedures .....	50
Cables .....	50
Fuses .....	50

### Group 38 Instruments, Contacts and Indicator/Warning Lights

Construction and Function .....	52
Service Procedures .....	58
Speedometer .....	58
Coolant temperature gauge .....	58
Fuel gauge .....	60
Changing the contact for oil pressure .....	61
Solenoid valve for front-wheel drive .....	61
Contact for brake lights .....	61
Contact for pressure difference in brake circuits ..	62
Contact for brake pedal movement .....	62
Contact for parking brake .....	62
Contact for reversing lights .....	63
Vacuum contacts for diff. locks .....	63
Contact for front-wheel drive (underneath instrument panel) .....	63
Contact for front-wheel drive (at transfer box) ....	64
Indicator/warning lights .....	64

### Group 39 Wiring Diagram

Wiring Diagram .....	Fold-out
----------------------	----------



# Group 30 General

## Specifications

### Battery

Type .....	Noack 12H60B or corresponding
Number .....	One
System voltage .....	12 V
Capacity .....	60 Ah
Electrolyte specific gravity:	
Fully charged battery .....	1.28
When re-charging should be done .....	1.21
Recommended charging current .....	6.0 A

### Alternator

Type .....	Bosch 14V/55A 0120400686
Output .....	770 W
Max. amperage .....	55 A
Max. speed .....	200 r/s (12000 r/min)
Direction of rotation .....	Clockwise
Ratio, engine-alternator .....	1:1.72
Rotor, resistance .....	4.0-4.4 ohm
Stator, resistance .....	0.14-0.15 ohm
Min.-diameter of slip rings .....	31.5 mm
Maximum permissible radial throw for slip rings .....	0.03 mm
Max. permissible radial throw for rotor body .....	0.05 mm
Min. length of brushes .....	14 mm
Brush spring force .....	3-4 N
Tightening torque for pulley .....	40 Nm (4 kgf m = 30 lbf ft)
Output test (at approx. 14 V)	
Alternator should generate min. 25A at alternator speed ..	25 r/s (1500 r/min)
engine speed .....	14.5 r/s (870 r/min)
Alternator should generate min. 55A at alternator speed ..	100 r/s (6000 r/min)
engine speed .....	58 r/s (3500 r/min)

### Charging regulator

Type .....	Bosch AD 14 V
Control voltage .....	At 67 alternator r/s (4000 r/min)
Engine speed .....	39 r/s (2300 r/min)
Cold regulator read off within 30 secs, lower pair of contacts .....	13.9-14.8 V
Load current (regulated by lower pair of contacts) .....	28-30 A
Load current (regulated by upper pair of contacts) .....	3-8 A

### Starter motor

Type .....	Bosch GF 12 V 1.1 Ps
Voltage .....	12 V
Direction of rotation .....	Clockwise
Output .....	Approx. 810 W (1.1 h.p.)
Number of brushes .....	4
Test values, mechanical	
Rotor end float .....	0.05-0.3 mm
Brush spring tension .....	11.5-13.0 N 1.15-1.30 kgf (2.5-3.0 lbf)



Distance from pinion to ring gear .....	1.2-4.4 mm (0.048-0.173")
Rotor brake frictional torque .....	0.22-0.40 Nm 2.2-4.0 kgf m (16-30 lbf ft)
Pinion idling torque .....	0.13-0.18 Nm 1.3-1.8 kgf m (9.5-13.0 lbf ft)
Backlash .....	0.35-0.50 mm (0.014-0.020")
Minimum diameter of commutator .....	33 mm (1.3")
Minimum length of brushes .....	13 mm (0.5)
Test values, electrical (with a battery capacity of 135 Ah)	
Unloaded starter motor 11.5 V and 30-50 A .....	96.7-130.0 r/s (5800-7800 r/min)
Locked starter motor (rotor) 6 V and 330-420 A .....	0 r/s
Control solenoid cut-in voltage .....	Min. 7.5 V

## Ignition system

Firing sequence .....	1-5-3-6-2-4
Ignition timing (vacuum governor disconnected) .....	10° at 13.3 r/s (800 r/min)
Basic firing position (engine switched off) .....	10° B.T.D.C.
Spark plugs .....	W 200 T 35 or corresponding
Spark plugs, electrode gap .....	0.7-0.8 mm
Spark plugs, tightening torque .....	35-40 Nm 3.5-4.0 kgf m (26-30 lbf ft)
Ignition coil, condenser .....	0.45 $\mu$ F
Spark plug cables, damper resistance at 20°C (68°F) .....	1000 $\Omega$ at distributor 5000 $\Omega$ at spark plug

## Distributor

Type .....	PFU 6
Direction of rotation .....	Anti-clockwise
Cam angle (dwell angle) .....	39°-45°
Breaker contacts, gap .....	Min. 0.25 mm (0.010")
contact pressure .....	5.0-6.3 N (0.5-0.63 kgf = 1-1.4 lbf)

## Centrifugal governor

Advance, total .....	11.5-13.5 distr. degrees
Advance begins at .....	10.2-12.1 distr. r/s (610-725 distr. r/min)
Values, 5° .....	14.3-16.7 distr. r/s (860-1000 distr. r/min)
10° .....	26.3-32.9 distr. r/s (1575-1975 distr. r/min)
Advance, maximum, at .....	37.5 distr. r/s (2250 distr. r/min)

## Vacuum governor (positive)

Advance, total .....	4-6 distr. degrees
Advance begins at .....	10.7-16.0 kPa (80-120 mm Hg) (3-5")
Values at 2.5 distr. degrees .....	15.3-21.3 kPa (115-160 mm Hg) (4.5-6.3")
Advance, maximum, at .....	23.3-25.3 kPa (175-190 mm Hg) (7-7.5")

## Lighting

### Bulbs

	Qty	Output	Socket	Type
Headlamps .....	2	60/55 W		H 4
Direction indicators .....	4	23 W	Ba 15 s	
Parking lights .....	2	4 W	Ba 9 s	
Stop lights .....	2	23 W	Ba 15 s	
Tail lights .....	2	10 W	Ba 15 s	
Interior lighting .....	2	10 W	S 8.5	

### Indicator and warning lights

Fullbeams .....	1	2 W	Ba 9 s
Direction indicators .....	2	2 W	Ba 9 s
Diff. locks .....	2	2 W	Ba 9 s
Front-wheel drive .....	1	2 W	Ba 9 s
Battery charging .....	1	2 W	Ba 9 s
Oil pressure .....	1	2 W	Ba 9 s
Brakes .....	1	2 W	Ba 9 s

### Instruments

Speedometer .....	1	2 W	Ba 9 s
Coolant temperature gauge .....	1	2 W	Ba 9 s
Fuel gauge .....	1	2 W	Ba 9 s

### Switches

Lights .....	1	2 W	Ba 7 s
Windscreen wipers .....	2	2 W	Ba 7 s
Washers .....	1	2 W	Ba 7 s
Hazard warning lights .....	1	2 W	Ba 7 s
Headlamp wipers .....	1	2 W	Ba 7 s

### Fuses

Qty	Rated current
18	8 A

## General Service Procedures

Before carrying out any repairs, disconnect the negative lead from the battery.

The cables have been coloured in order to facilitate identification.

The following cable colours are used:

Blue	Green	Black
BL	GN	SB
Brown	Yellow	Grey
BN	Y	GR

When about to do any electrical welding work on the vehicle, disconnect both battery cables and the cables to the charging alternator. The welding machine should be connected as near as possible to where the welding is to take place and on the same main component. For example, if the frame is to be welded, the welding machine should be earthed to the frame.

A layout wiring diagram has been made for the following connections:

Connection	Group Illustration
Lighting, instruments and switches	35
Windscreen headlamp washers (hose routing)	36
Direction indicators with hazard warning flashers	36
Windscreen wipers with relay	36
Windscreen wiper parking	36
Headlamp wipers	36
Coolant temperature gauge with sender	38
Fuel gauge with sender	38
Engaging front-wheel drive	38
Engaging vacuum contacts	38
Warning devices for warning lamp marked "Brake"	38

### Connection designations on various components

The listing below is to show the association between wire connection and the component terminal designation.

From

To

### Group 31


Battery  
Starter motor  
Starter motor

30 Starter motor  
B+ Alternator  
30 Ignition switch



From

To



# Group 31. Battery

## Construction and Function




Fig. 31-1. Battery

### attery

ie battery is situated on the left-hand side, behind the driver's seat.

consists of a 12-volt lead-type battery with a capacity 60 Ah.

ie battery negative pole (-) is wired to the vehicle chassis.

### apacity

ie capacity of the battery is given in ampère hours (abbreviated Ah). When we say that a battery has a capacity twenty hours, we mean that the battery develops, e.g., 3 A during 20 hours. It then has a capacity of 60 Ah.

The capacity of a battery depends among other things on its ambient temperature. A low temperature has a negative effect on the capacity. When we indicate the capacity of a battery, we very often mean the capacity at 20°C (68°F).

Capacity differences at different temperatures:

100 % capacity at 20°C (68°F) gives about 55 % capacity at -18°C (0°F)

70 % capacity at 20°C (68°F) gives about 35 % capacity at -18°C (0°F)

40 % capacity at 20°C (68°F) gives about 25 % capacity at -18°C (0°F).

## Service Procedures

### Battery

When replacing the battery, make sure that the new one is connected up with the correct polarity (minus to vehicle chassis).

The battery cables must not be disconnected when the engine is running.


To ensure that the battery operates without any trouble, always maintain the fluid at the prescribed level. Make sure that it is about 5 mm (3/16") above the cell plates. Top-up if necessary with sufficient distilled water. Also make sure that the battery cable shoes are fixed securely. The cable shoes and pole studs should be coated with a light layer of grease, e.g., Bosch Ft 40 V 1 or corresponding.

### 31102-3


#### Changing the battery

##### Removal

1. Unclasp the lock clasps and fold down the cover.



2. Remove the insulation across B+.
3. Disconnect the battery cables from the battery.
4. Remove the battery.




##### Installation

1. Place the battery in the battery box.
2. Grease the studs and cable shoes with suitable grease, e.g., Bosch Ft 40 V 1 or corresponding.
3. Connect the battery cables to the battery and fit the insulation across B+. Fit the cover over the battery.



## Group 32. Alternator

### Construction and Function



122 096

Fig. 32-1. Alternator

- 1 Battery charging warning light
- 2 Charging regulator
- 3 Alternator

#### alternator

The alternator is situated on the right-hand side of the engine and is driven by two belts from the crankshaft pulley. The alternator develops an output of max. 770 W.

The charging regulator is mounted on the right-hand side of the rear engine casing lock device. The battery charging warning light is on the instrument panel.